



Quality Refrigeration

INTELA-TRAUL® MASTER SERVICE MANUAL



*For All Full Size Undercounter, G-Series and
R&A Series Refrigerator, Freezer, Dual-Temp
and Hot Food Unit Controllers*

Traulsen

4401 Blue Mound Road - Fort Worth, Texas 76106

Phone: (800) 825-8220 or (817) 625-9671

Fax-Service (817) 740-6757

TABLE OF CONTENTS

| | |
|---|-------------|
| I. General Information | |
| a) How To Use This Manual | Page 2 |
| b) About INTELA-TRAUL | Page 2 |
| c) Operating The Controller | Page 2 |
| II. Basic Service Procedures | |
| a) Adjusting The Temperature | Page 3 |
| b) Starting A Manual Defrost Cycle (R & A Series) | Page 4 |
| c) Starting A Manual Defrost Cycle (G-Series) | Page 5 |
| III. Troubleshooting | |
| a) Checking For Defective Sensors | Page 6 |
| b) Checking For Failed Relays | Page 7 |
| c) Checking For Other Failed Components | Page 8 |
| d) Checking For Iced Evaporator Coil | Page 9 |
| e) Proper Sensor Placement | Page 10 |
| IV. Control Architecture | |
| a) R & A Series Refrigerator & Freezer Vertical Controllers | Page 11-14 |
| b) Undercounter Refrigerator & Freezer Horizontal Controllers | Page 15 |
| c) G-Series Refrigerator & Freezer Vertical Controllers | Page 16-17 |
| d) R & A Series Heated Cabinet Vertical Controllers | Page 18-20 |
| V. Removal/Installation | |
| a) All Vertical Controllers | Pages 21-22 |
| b) All Horizontal Controllers | Page 23 |
| VI. Problem Diagnosis | |
| a) How To Use Troubleshooting Trees | Page 24 |
| b) Hi-Temp Alarm (all HT/RI & LT/IF models) | Page 25 |
| c) Lo-Temp Alarm (all HT/RI & LT/IF models) | Page 26 |
| d) Door Open Alarm (all HT/RI, LT/IF HF/IH models) | Page 27 |
| e) Power Loss Alarm (all HT/RI, LT/IF HF/IH models) | Page 28 |
| f) System Leak Alarm (all HT/RI & LT/IF models) | Page 29 |
| g) Condenserclean Alarm (all HT/RI & LT/IF models) | Page 30 |
| VII. Accessing The Engineering Level | Page 31 |
| VIII. Control Parameters | |
| a) Parameter Descriptions | Page 32-33 |
| b) Parameter Access & Units Of Measurement | Page 34 |
| c) G-Series Parameter Settings | Page 35 |
| d) R-Series Parameter Settings - Refrigerator Models | Page 36 |
| e) R-Series Parameter Settings - Freezer Models | Page 37 |
| f) Undercounter Parameter Settings | Page 38 |

I. GENERAL INFORMATION

I. a - HOW TO USE THIS MANUAL:

Traulsen provides this manual as an aid to the service technician in installation, operation, and maintenance of INTELA-TRAUL® Controllers. When used properly, this service manual can help the service technician maintain, troubleshoot and diagnose most of the problems and malfunctions that may occur with the Controllers.

This manual covers the four different types of Controllers (**Full Size Undercounter, G-Series, R&A Series Refrigerator & Freezer, and R&A Series Hot Food**). These vary slightly from one another, all exceptions are noted, and where appropriate separate sections are provided.

While we believe that most aspects of the controllers are covered in this manual, should you encounter a condition not addressed, or require a wiring diagram please contact:

Traulsen
4401 Blue Mound Road Fort Worth, TX 76106
Attn: Service Department
Phone: (800) 825-8220 or (817) 625-9671
Fax: (817) 740-6757

All service communication must include:

- Model Number & Serial Number Of Unit
- A detailed explanation of the problem

I. b - ABOUT INTELA-TRAUL:

The Traulsen INTELA-TRAUL and G-Series microprocessor controls are microprocessor based systems which replace several electromechanical components typically built into refrigeration products, such as: time clocks, thermometers, defrost limit switches and temperature controls, all combined into one solid state modular unit.

These microprocessor controls both monitor a cabinet air sensor and a coil sensor. The INTELA-TRAUL on the R & A Series also includes a discharge line sensor and a relative humidity sensor (H1 versions only). In conjunction with the programmed parameters of the control, and the information received, it cycles the refrigeration system ON and OFF at set temperatures, initiates and/or terminates defrost cycles, and initiates one of several alarm features if a problem is sensed (R & A Series only). R & A Series controls also allow the operator to cycle the door perimeter heaters ON/OFF as needed.


















I. c - OPERATING THE CONTROLLER:

When operating the controller it is important to note that you only have approximately 20-30 seconds between button pushes. If you take longer than 30 seconds, the controller will revert back to displaying the cabinet temperature. If you enter the wrong security code, the controller will revert back to displaying the cabinet temperature. You can exit the parameters at any time by waiting 20-30 seconds for the control to return to normal operation.









II. BASIC SERVICE PROCEDURES

II. a - ADJUSTING THE TEMPERATURE:



The Display
Will Read

- Step 1: Press . Display will read "CUS." 
- Step 2: Press . Display will read "000" with the left digit flashing. 
- Step 3: Press . Display will read "000" with the center digit flashing. 
- Step 4: Press  until the center digit changes to an "A". 
- Step 5: Press . Display will read "0A0" with the right digit flashing. 
- Step 6: Press  until the right digit changes to a "1". 
- Step 7: Press . Display will read "SPH". 
- Step 8: Press  again.
- Step 9: Press  or  to adjust temperature to desired setting.

(NOTE: SPH should be set at 38 to 40°F for refrigerators and 0°F for freezers)

- Step 10: When display reads the desired temperature press . 
- Step 11: Press  until display reads "SPL". 
- Step 12: Press .
- Step 13: Press  or  to adjust temperature to desired setting. 













(NOTE: SPL should be set at 34°F for refrigerators and -4°F for freezers)

- Step 14: Press .
- Step 15: Press  to exit (R & A Series only). On G-Series models the controller will automatically revert back to normal temperature display operation after a delay of approximately 20-30 seconds.

II. BASIC SERVICE PROCEDURES

II. b - STARTING A MANUAL DEFROST CYCLE (R & A Series):

The Display
Will Read

- Step 1: Press . Display will read "CUS."
- Step 2: Press . Display will read "000" with the left digit flashing.
- Step 3: Press . Display will read "000" with the center digit flashing.
- Step 4: Press  until the center digit changes to an "A".
- Step 5: Press . Display will read "0A0" with the right digit flashing.
- Step 6: Press  until the right digit changes to a "1".
- Step 7: Press . Display will read "SPH".
- Step 8: Press  until the control reads "Sd," Start Manual Defrost.
- Step 9: Press . Display will read "n" (NO).
- Step 10: Press  or . Display will read "4" (YES).
- Step 11: Press . Controller will display "SPH" for 30 seconds and then "DEF" will appear.



NOTE: The controller will automatically revert back to normal operation after a delay of approximately 20-30 seconds.




























NOTE:

Traulsen R & A Series refrigerator models also include an off-cycle defrost feature, which occurs once an hour. This is indicated by the control display, is time or temperature terminated, and generally is of 3 - 10 minutes in duration.

II. BASIC SERVICE PROCEDURES

II. c - STARTING A MANUAL DEFROST CYCLE (G-Series):

The Display
Will Read

- | | |
|--|---|
| Step 1: Press  . Display will read "CUS." |  |
| Step 2: Press  . Display will read "000" with the left digit flashing. |  |
| Step 3: Press  . Display will read "000" with the center digit flashing. |  |
| Step 4: Press  until the center digit changes to an "A". |  |
| Step 5: Press  . Display will read "0A0" with the right digit flashing. |  |
| Step 6: Press  until the right digit changes to an "1". |  |
| Step 7: Press  . Display will read "SPH". |  |
| Step 8: Press  until the control reads "Sd," Start Manual Defrost. |  |
| Step 9: Press  . Display will read "n" (NO). |  |
| Step 10: Press  or  . Display will read "4" (YES). |  |
| Step 11: Press  . Display will then read "SPH," Start Manual Defrost. |  |
| Step 14: Press  or  to scroll to the next parameter, otherwise the controller will automatically revert back to normal operation after a delay of approximately 20-30 seconds. | |



NOTE:

Traulsen G-Series refrigerator models also include an off-cycle defrost feature, which occurs once an hour. This is indicated by the control display, is time terminated, and is generally of 3 - 10 minutes in duration.

The defrost cycle on Traulsen G-Series freezer models can be either time or temperature terminated.

DEFROST ICON


III. TROUBLESHOOTING

III. a - CHECKING FOR DEFECTIVE SENSORS:


The Display
Will Read

Step 1: Press . Display will read "CUS."




Step 2: Press . Display will read "000" with the left digit flashing.




Step 3: Press . Display will read "000" with the center digit flashing.




Step 4: Press  until the center digit changes to an "A".



Step 5: Press . Display will read "0A0" with the right digit flashing.



Step 6: Press  until the right digit changes to an "1".





Step 7: Press .

Step 8: Press  until display reads "EL". Press .



If the display now reads "-40," check for loose connection on the EVAPORATOR sensor. If the display has a very high reading such as "266," replace the evaporator sensor.



NOTE: Erroneous readings may be the result of a faulty sensing circuit (open or shorted) in the Controller.

Step 9: Press  until the display reads "DL¹". Press .



In the event that the display now reads "-40," check for a loose connection on the DISCHARGE LINE sensor. If the display has a reading of "220" or higher, check for lack of adequate air-flow through the condenser, a bad condenser motor, or any other condition around the unit which could cause a high temperature, such as a steam table or a crossdraft. Otherwise, proceed with replacing the DISCHARGE LINE sensor.

NOTE: Erroneous readings may be the result of a faulty sensing circuit (open or shorted) in the Controller.

Step 10: Press  until the display reads "AA²". Press .



Display should read the approximate ambient air temperature behind the louver panel. If the display reads "111" check for a loose connection on the RH/AMBIENT AIR sensor. If the display reads "32.0" check the sensor for a short circuit.

NOTE: If display reads -40 or 266 the cabinet sensor is defective and requires replacement.

NOTE: Ambient Air Sensor not included on MIT version controllers.

NOTE: Erroneous readings may be the result of a faulty sensing circuit (open or shorted) in the Controller (on H1 control version only).

1= DL is not included on G-Series controllers.

2= AA is not available with MIT version controllers.

III. TROUBLESHOOTING

III. b - CHECKING FOR FAILED RELAYS:

Checking For A Failed Internal Controller Relay:

1. Gain access to Controller compressor relay (see REMOVAL INSTRUCTIONS within this service manual for the specific type of controller your are servicing).
2. Locate the connector with the black/blue/purple wires and unplug it. Refer to the schematic on the side of the controller, or refer to the appropriate wiring diagram (to obtain this please contact the factory, referencing the serial number of the unit involved).
3. Using a volt/ohm meter (VOM) with the power OFF, check the resistance across the black to blue wires of the Controller connector. If completed circuit is indicated (with no power to the Controller), the contacts are stuck closed and the Controller should be replaced (on MIT versions either the relay box or one of the other relays within the unit need to be replaced).

Checking For A Failed External "Slave" Relay or Solid State Relay (SSR), p/n 337-60360-01 (MIT II Only):

1. Gain access to the controller compressor relay (see REMOVAL INSTRUCTIONS within this service manual for the specific type of controller your are servicing).
2. Locate the external "slave" relay and unplug the harness connectors.
3. Using a volt/ohm meter (VOM), check the resistance from the "COM" terminal to the "NO" terminal. If a completed circuit is indicated, the contacts are stuck closed and the slave relay should be replaced.
4. For the SSR, remove the black and blue wires from terminals 3 & 4. Using a volt/ohm meter, and with the power OFF, measure the resistance across the terminals. A completed circuit indicates that the circuit is closed and that the relay should be replaced. A reading of 25 m Ω to 35 m Ω is considered normal for an open circuit in the SSR.

Checking For A Failed Door/Light Relay (R & A Series models only):

1. Gain access to Controller door relay (see REMOVAL INSTRUCTIONS within this service manual for the specific type of controller your are servicing).
2. Remove the wire from the door relay coil.
3. Using a volt/ohm meter (VOM), check across the relay contacts. If an open across the contacts is not indicated, replace the door relay.

NOTE: Equipment manufactured with the MIT II controller version do not include a Door/Light relay).

4. Physically check the switch for evidence of water. If switch has water in it, proceed with replacing the switch.

III. TROUBLESHOOTING

III. c - CHECKING FOR OTHER FAILED COMPONENTS:

Checking For A Failed Door Switch:

1. Remove the door(s) from the unit involved.
2. Locate the door switch, which is located behind the top door hinge(s).
3. Remove the switch from the cabinet.
4. Using a volt/ohm meter (VOM), check across the switch contacts. "COM" to "NO" should read open. If not, replace the switch.
5. Reinstall the switch and hinge onto the cabinet.

NOTE: If the unit has more than one door, check ALL door switches in the same manner as described in steps 1 thru 5 above.

Checking For A Failed Controller Transformer (H1 & MIT I control versions only):

1. Check incoming voltage. Voltage at the unit must be within the ranges shown in the table below.

| VOLTAGE | | |
|--------------------------|--------------------------|-------------------------------|
| MIN | MAX | STANDARD |
| 104 VAC | 126 VAC | 115/60/1 |
| 187 VAC | 253 VAC | 208-230/60/1 |
| 10.2 Volts (MIT 12.4) | 13.8 Volts (MIT 14.7) | Transformer Output Voltage |


2. If the controller display does not come back on, use a volt/ohm meter (VOM) and check the output voltage of the controller transformer.
3. If the output voltage from the transformer is not within the range shown in the table above, replace the transformer. If the transformer tests OK, replace the controller instead.
4. For equipment manufactured with the MIT II controller version the transformer is mounted inside the relay module. Check between 17 and 8 on 18 pin connector on relay module for 12V DC.

Checking Cabinet, Coil or Discharge Line Sensors:

1. Gain access to CABINET, COIL or DISCHARGE LINE sensor and disconnect it.
2. Place tip of sensor probe in a mixture of icewater for several minutes. Allow enough time for sensor probe to acclimate to the icewater.
3. At 32°F, probe resistance should be 32.7K Ohms, +/- 10%. If resistance is not within this range, replace the sensor.

III. TROUBLESHOOTING

III. d - CHECKING FOR ICED EVAPORATOR COIL:




III. TROUBLESHOOTING

III. e - PROPER SENSOR PLACEMENT:

Coil Sensor:


The coil sensor should be inserted into the return air side of the evaporator coil. On freezer models only this sensor should be centered approximately 2" (two inches) from the top (horizontally through coil - centered in coil).

On refrigerator models this sensor should be mounted on top of the coil.




Cabinet Air Sensor:

The cabinet air sensor should be mounted inside the evaporator housing (hump) on the return air side of the evaporator coil.




Discharge Sensor (R & A Series Only):

The discharge air sensor should be mounted on the hot gas side of the compressor. Placement should be as close to the compressor as possible and must be placed prior to the beginning of the hot gas loop. Please note that discharge sensors must be insulated.



IV. CONTROL ARCHITECTURE


IV. a - R & A SERIES REFRIGERATOR & FREEZER VERTICAL CONTROLLER:



NOTES: IRDA not included on equipment manufactured with the MIT II control version.

See parts assembly on pages 12-13.

IV. CONTROL ARCHITECTURE



COIL SENSOR³
P/N 337-60071-02




DISCHARGE SENSOR³
P/N 337-60072-00



CABINET SENSOR³
P/N 337-60069-02



HORN³
P/N 337-60070-00




RH SENSOR³
P/N 337-60080-00
(control versions H only)


³= Component can be ordered separately.

IV. CONTROL ARCHITECTURE

IV. b - R & A SERIES REFRIGERATOR & FREEZER VERTICAL CONTROLLER: Parts assembly for H1 thru MIT control versions only



MIT CONTROL TROUBLE SHOOTING DIAGRAM



NOTE


All pins in this connection should not read more than 20 VAC



| Connector Pin No. | Color | Signal |
|-------------------|--------------|-----------------------|
| 1 | Gray | Blower* |
| 2 | Orange | Door Heater* |
| 3 | Green | Alarm From Controller |
| 4 | | |
| 5 | | |
| 6 | Brown | |
| 7 | White/Purple | -RS485 |
| 8 | Black | Ground |
| 9 | Yellow/Red | 12 VAC |
| 10 | Blue | Compressor* |
| 11 | Purple | Defrost* |
| 12 | Yellow | Door Open Signal |
| 13 | Red | Power to Horn |
| 14 | Orange | |
| 15 | White | |
| 16 | Pink | +RS485 |
| 17 | Red | 12 VDC to Controller |
| 18 | | |

IV. CONTROL ARCHITECTURE


IV. c - UC & UL (UNDERCOUNTER) HORIZONTAL CONTROLLER:




IV. CONTROL ARCHITECTURE

IV. c - UC & UL (UNDERCOUNTER) HORIZONTAL CONTROLLER:

Parts assembly for MIT control version only



MIT CONTROL TROUBLE SHOOTING DIAGRAM



NOTE
All pins in this connection should not read more than 20 VAC




| Connector Pin No. | Color | Signal |
|-------------------|--------------|-----------------------|
| 1 | Gray | Blower* |
| 2 | Orange | Door Heater* |
| 3 | Green | Alarm From Controller |
| 4 | Black | Return From Horn |
| 5 | | |
| 6 | | |
| 7 | White/Purple | -RS485 |
| 8 | Black | Ground |
| 9 | White | 12 VAC |
| 10 | Blue | Compressor* |
| 11 | Purple | Defrost* |
| 12 | Yellow | Door Open Signal |
| 13 | Red | Power to Horn |
| 14 | | |
| 15 | | |
| 16 | Pink | +RS485 |
| 17 | Red | 12 VDC to Controller |
| 18 | Black | 12 VAC |

*Voltage should not be more than 5 DC when measured to ground (pin 8).


IV. CONTROL ARCHITECTURE

IV. d - G-SERIES REFRIGERATOR & FREEZER VERTICAL CONTROLLER:



IV. CONTROL ARCHITECTURE


IV. d - G-SERIES REFRIGERATOR & FREEZER VERTICAL CONTROLLER:



| CONNECTOR PIN NUMBER | COLOR | SIGNAL |
|----------------------|------------|-----------------------|
| 1 | | |
| 2 | GRAY | BURGER |
| 3 | | |
| 4 | | |
| 5 | | |
| 6 | | |
| 7 | | |
| 8 | BLACK | GROUND |
| 9 | YELLOW/RED | POWER LINE FAILURE |
| 10 | BLUE | COMPRESSOR |
| 11 | PURPLE | DEFROST |
| 12 | | |
| 13 | ORANGE | 3 VDC FROM CONTROLLER |
| 14 | | |
| 15 | | |
| 16 | RED | 12 VDC TO CONTROLLER |

IV. CONTROL ARCHITECTURE

IV. e - R-SERIES HEATED CABINET VERTICAL CONTROLLER:



NOTES: IRDA not included on equipment manufactured with MIT II control version.

See parts assembly on pages 17-18.

HOT FOOD CABINET START-UP (pre-MIT version):

When power is first applied to the unit, you must set the temperature by pressing the "SET" and "UP ARROW" buttons at the same time using equal pressure with both thumbs, until the temperature appears on the display. Next, use the "UP" button to reach the desired temperature (maximum 180°), then press and release the "SET" button to lock it in.

After this is done you can turn the control ON and OFF by pressing and releasing the "ALARM CANCEL" button.

Be aware to watch for the display constantly reading "OFF". This is an indication of a possible faulty cabinet sensor. To remedy, replace the sensor and reset the operating temperature.

HOT FOOD CABINET START-UP (MIT version):

The MIT control offers an additional means of turning the cabinet heaters ON and OFF. After the operating temperature has been set, the operator can continuously turn the unit OFF and then back ON again to the same operating temperature by pressing the "ON/OFF" button on the face of the control.

Please note that this feature will not function if the control is in an alarm state with the alarm LED illuminated.


IV. CONTROL ARCHITECTURE

IV. e - R-SERIES HEATED CABINET VERTICAL CONTROLLER:

Parts assembly for H1 control versions only


1= Set of two (can be ordered separately).

2= Requires unit model number and serial number to place order.




IV. CONTROL ARCHITECTURE

IV. e - R-SERIES HEATED CABINET VERTICAL CONTROLLER: Parts assembly for MIT control versions only



MIT CONTROL TROUBLE SHOOTING DIAGRAM



NOTE

All pins in this connection should not read more than 20 VAC



| Connector Pin No. | Color | Signal |
|-------------------|--------------|-----------------------|
| 1 | Gray | Blower* |
| 2 | Orange | Door Heater* |
| 3 | Green | Alarm From Controller |
| 4 | Black | Return To Horn |
| 5 | | |
| 6 | | |
| 7 | White/Purple | -RS485 |
| 8 | Black | Ground |
| 9 | White | 12 VAC |
| 10 | Blue | Compressor* |
| 11 | Purple | Defrost* |
| 12 | Yellow | Door Open Signal |
| 13 | Red | Power to Horn |
| 14 | | |
| 15 | | |
| 16 | Pink | +RS485 |
| 17 | Red | 12 VDC to Controller |
| 18 | Black | 12VAC |


*Voltage should not be more than 5 DC when measured to ground (pin 8).

V. REMOVAL/INSTALLATION


V. a - ALL VERTICAL CONTROLLERS:

To remove INTELA-TRAUL® (p/n's 337-60090-00, 337-60091-00 and 337-60092-00) and G-Series (p/n's 337-60093-00, 337-60094-00 and 337-60095-00) Vertical Controller from the unit in which it is installed, proceed as follows (If unable to access the unit from the rear perform steps 1 through 3, otherwise, proceed to step 4):


(2) SLOT HEAD THUMBSCREWS




1. At front of unit, remove two (2) slot head thumb screws from bottom corners of louver assembly. Set thumbscrews aside.



(2) SLOT HEAD THUMBSCREWS




2. Swing louver assembly up and away from front of unit until it stops.
3. Remove two (2) Slot head thumbscrews from top of louver assembly. Set thumbscrews and louver assembly aside.




V. REMOVAL/INSTALLATION

WARNING: DISCONNECT ALL POWER BEFORE PROCEEDING

4. At the top of the junction box, remove three (3) Phillips head screws. Set screws aside.
5. Locate one (1) Phillips head screw at bottom of junction box, and remove. Set screw aside.




6. Carefully slide junction box away from front of unit until all wiring and connections to the controller are exposed.
7. Locate all nine (9) Controller connections (five for G-Series), then carefully disconnect each one.




8. Firmly grasp and compress the rounded portion of the middle prong on each holder clip. Slowly slide each holder clip off the controller. Set clips aside.

NOTE:

Be sure ALL components have been disconnected from the Controller before performing the next step.



9. Slowly pull Controller through mounting hole and set aside.






TO RE-INSTALL CONTROLLER, REVERSE THE PRECEEDING PROCEDURE.

V. REMOVAL/INSTALLATION

V. a - ALL HORIZONTAL CONTROLLERS:

To remove INTELA-TRAUL® (p/n's 337-60096-00 and 337-60097-00) Horizontal Controller from the unit in which it is installed, proceed as follows:

WARNING: DISCONNECT ALL POWER BEFORE PROCEEDING



1. Check to make sure that the power cable is disconnected from the wall.
2. Remove the four (4) black plugs that are located in each corner of the power pack louver assembly. Set plugs aside.
3. Remove the four (4) Phillips head screws holding the louver assembly in place. Set screws and louver assembly aside.
4. Remove the two (2) Phillips head screws that hold the Controller and the bracket assembly to the condenser fan assembly. Set screws aside.
5. Locate all nine (9) Controller connections, then carefully disconnect each one.
6. Firmly grasp and compress the rounded portion of the middle prong on each holder clip. Slowly slide each holder clip off the Controller. Set clips aside.


TO RE-INSTALL CONTROLLER, REVERSE THE PRECEDING PROCEDURE.

VI. PROBLEM DIAGNOSIS

VI. a - HOW TO USE THE TROUBLESHOOTING TREES:

The troubleshooting trees on the following pages were developed as an aid to the service technician in determining the exact solution to a certain problem or malfunction. When used as designed, the troubleshooting trees can lead you from a general symptom to the most likely component to suspect as the cause of the problem.


The trees are made up of three different types of boxes:



QUESTION



CHECK



SOLUTION

QUESTION

Boxes ask a yes/no question and the answer will lead to either another question box, a check box, or a solution box.

CHECK


Boxes will suggest a point to check for proper operation, and will often refer you to a page in either the SERVICE INFORMATION or the REMOVAL/INSTALLATION sections of this manual. The result of the check may lead to another box, or a solution box.

SOLUTION

Boxes suggest the most likely component to cause the malfunction described in the heading of the tree. When reaching a solution box, do not immediately assume the component is defective. The final step is to use the SERVICE INFORMATION section of this manual to verify that the component is defective.


To use the troubleshooting trees, first find the page with the heading describing the type of problem occurring. Begin at the top of the page and follow the tree, step-by-step. When a check box is reached, refer to the suggested section to make the check suggested. Once a solution box is reached, refer to the suggested section to verify that the component in the solution box is indeed defective, and repair or replace per the direction in that section.

VI. b- HIGH TEMPERATURE ALARM



¹= See procedure on page 9.


VI. c- LOW TEMPERATURE ALARM



NOTE ON HOT FOOD UNITS ONLY

Hot food units are designed to hold hot food at set temperature. The cabinet is not designed to heat cold products.


VI. d- DOOR OPEN ALARM



1= H1 and MIT 1 control versions only.


2= See procedure on page 7.

VI. e- POWER LOSS ALARM




1= See procedure on page 8.

VI. f- SYSTEM LEAK ALARM



¹= See procedure on page 8.





















VI. g - CONDENSERCLEAN ALARM




VII. ACCESSING THE ENGINEERING LEVEL

VII. a - ACCESSING THE ENGINEERING LEVEL:

Not all control parameters can be adjusted at the customers level of access. To adjust these other parameters it is first necessary to gain access to the ENGINEERING LEVEL. Please follow the below procedure in order to enter this level.

- | | The Display
Will Read |
|---|---|
| Step 1: Press  . Display will read "CUS." |  |
| Step 2: Press  until "EnG" is displayed. |  |
| Step 3: Press  . Display will read "000" with the left digit flashing. |  |
| Step 4: Press  until the left digit changes to an "9". |  |
| Step 5: Press  . Display will read "900" with the center digit flashing. |  |
| Step 6: Press  until the center digit changes to an "9". |  |
| Step 7: Press  . Display will read "990" with the right digit flashing. |  |
| Step 8: Press  until the right digit changes to an "E". |  |
| Step 9: The display will read (99E), press  . |  |
| Step 10: Press  . The display will now read "FOC" - See Note. |  |

NOTE: R & A Series Only, for G-Series models press  for the control to display "FOC."

VIII. CONTROL PARAMETERS

VIII. a - PARAMETER DESCRIPTIONS:

| | |
|-----|---|
| FOC | 3-digit code which identifies the .hex file loaded at the factory. |
| ADR | Device address for NAFEM networks. |
| BAU | Communications rate when connected into a NAFEM network. |
| NAF | Allow the control to communicate with a NAFEM network. |
| SPH | High value of desired cabinet temperature range. |
| SPL | Low value of desired cabinet temperature range. |
| SHL | Lowest temperature of allowed range for setting of SPH. |
| SHH | Highest temperature of allowed range for setting of SPH. |
| SLL | Lowest temperature of allowed range for setting of SPL. |
| SLH | Highest temperature of allowed range for setting of SPL. |
| RO | Difference, in degrees, between displayed & measured temperature. |
| HI | The highest temperature the cabinet air temperature is allowed to reach before triggering a High-Temp alarm. |
| LO | The lowest temperature the cabinet air temperature is allowed to reach before triggering a Low-Temp alarm. |
| SCL | Sets the temperature display scale (fahrenheit or celsius). |
| HAD | Time, in minutes, that the controller delays triggering the High-Temp alarm at any start-up or at the end of a defrost cycle. |
| LAD | Time, in minutes, that the controller delays triggering the Low-Temp alarm if cabinet air temperature equal or below SPL setting. |
| AC | The amount of time, in minutes, that the compressor must be off between cycles. |
| DEF | Defines the type of heat used to defrost the coil: Electric, Hot Gas, None or Off-Cycle. |
| IBD | The amount of time, in hours, between the end of the drip time& start of the next defrost cycle. |
| DDC | The maximum amount of time, in minutes, that the heat will be on during a defrost cycle. |
| CDE | The temperature of the evaporator coil that indicates the end of a defrost heat cycle. |
| DDE | The amount of time, in minutes, between the defrost heat being turned off and the compressor turning on. |
| BDD | The delay time, in minutes, between the end of the drip time and and before the evaporator blower turns on. |
| BSD | The temperature of the evaporator coil that triggers the evaporator blower to turn on after drip time ends. |
| ODD | The maximum amount of time, in minutes, that the display will read the last temperature recorded before entering the defrost cycle. |
| SD | Allows a technician to start or stop a defrost cycle. |
| CFA | Allows the customer to turn the clogged filter alarm ON/OFF (R & A Series only). |
| CCR | The minium amount of time, in minutes, that the compressor must be running before generating a clogged filter alarm. |
| CDL | The discharge line temperature that will trigger a clogged filter alarm. |
| DOA | Allows the customer to turn the door open alarm ON/OFF in units equipped with the appropriate hardware. |
| DAD | The time, in minutes, that a door must be open before triggering a door open alarm. |

VIII. CONTROL PARAMETERS

VIII. a - PARAMETER DESCRIPTIONS (continued):

| | |
|-----|---|
| APD | The amount of time, in seconds, that a visual alarm text will be displayed. |
| ATD | Alarm temperature delay. |
| AAS | Allows the customer to set the type of audible alarm style, either Blast, OFF or Continuous. |
| CL | Allows the customer to set the time of day. |
| DAY | Allows the customer to set the date. |
| DS | Sets daylight savings time On or OFF. |
| DL1 | Selects the time to start a defrost lockout. |
| DL2 | Selects the time to start a defrost lockout. |
| DL3 | Selects the time to start a defrost lockout. |
| DL4 | Selects the time to start a defrost lockout. |
| DCF | Allows the customer to set the percentage of time that the door perimeter heaters will operate, to control surface condensation. |
| CON | The amount of time the compressor will run in the event of a cabinet air sensor failure. |
| COF | The amount of time, in minutes, that the compressor will be OFF in the event of a cabinet air sensor failure. |
| EL | Displays the evaporator temperature at the time (press set or the up arrow button to display this feature). |
| DL | Displays the discharge line temperature at the time (press set or the up arrow button to display this feature). |
| CB | When activated (by pressing the set or up arrow buttons), will display the cabinet air temperature at the time the button is pressed. |
| PLn | When activated will display the approximate line voltage. |
| RCO | Will energize the compressor relay for 10 seconds when activated. |
| RdF | Will energize the heater relay for 10 seconds when activated. |
| RFA | Will energize the blower relay for 10 seconds when activated. |
| RDH | Will energize the door heater relay for 10 seconds when activated. |
| Pro | Parameter used only when reflashing the program memory. |
| CEP | When activated, will return all of the parameters to the initial factory settings. |
| REF | Displays the revision level of the software loaded into memory. |

VIII. CONTROL PARAMETERS

VIII. b - PARAMETER ACCESS & UNITS OF MEASUREMENT:

H1, MIT I & MIT II CONTROL VERSIONS ONLY

| Control Parameter | Description | Access | Unit of Measure |
|-------------------|--|--------|------------------|
| ADR* | Device Address | ENG | |
| BAU* | Comm. Baud Rate in K | ENG | KBaud |
| NAF* | NAFEM Communications Enable | ENG | On/Off |
| SPH | Temperature Set-Point High | CUS | Degree |
| SPL | Temperature Set-Point Low | CUS | Degree |
| SHL | Set-Point High/Low | ENG | Degree |
| SHH | Set-Point High/High | ENG | Degree |
| SLL | Set-Point Low/Low | ENG | Degree |
| SLH | Set-Point Low/High | ENG | Degree |
| RO | Room Offset | CUS | Degree |
| HI | Upper Temperature Limit | ENG | Degree |
| LO | Lower Temperature Limit | ENG | Degree |
| SCL | Temperature Scale | CUS | F or C |
| HAD | High-Temperature Alarm Delay | ENG | Minute |
| LAD | Low-Temperature Alarm Delay | ENG | Minute |
| AC | Anticycling | ENG | Minute |
| DEF | Defrost Type | ENG | Electric/Gas/Off |
| IBD | Intervals Between Defrosts | ENG | Hours |
| DDC | Maximum Defrost Duration | ENG | Minute |
| CDE | Coil Temperature At End of Defrost Cycle | ENG | Degree |
| DDE | Drip Time At End of Defrost Cycle | ENG | Minute |
| BDD | Blower Delay At Drip Time | ENG | Minute |
| BSD | BSD After Defrost End | ENG | Degree |
| ODD | Display Hold After Defrost | ENG | Minute |
| SD | Start/Stop Defrost | CUS | Start/Stop |
| CFA | Clogged Filter Alarm | n/a | On/Off |
| CCR | Clogged Filter Compressor Run Time | n/a | Minute |
| CDL | Clogged Filter Alarm Temperature | n/a | Degree |
| DOA | Door Open Alarm | ENG | On/Off |
| DAD | Door Display Alarm Delay | ENG | Minute |
| APD | Alarm Pause Delay | ENG | Second |
| ATD | Alarm Temperature Delay | ENG | Second |
| AAS | Audible Alarm Style | CUS | On/Off |
| CL | Set The Clock Time | CUS | H/N/S |
| DAY | Set The Clock Date | CUS | Y/N/D |
| DS | Daylight Savings | CUS | On/Off |
| DL1 | Defrost Lockout 1 | CUS | Time/Off |
| DL2 | Defrost Lockout 2 | CUS | Time/Off |
| DL3 | Defrost Lockout 3 | CUS | Time/Off |
| DL4 | Defrost Lockout 4 | CUS | Time/Off |
| DCF | Dewpoint Correction Factor | CUS | % |
| CON | Compressor Default On Time | ENG | Minute |
| COF | Compressor Off Time | ENG | Minute |
| EL | Evaporator Coil Temperature | CUS | Degree |
| DL | Discharge Line Temperature | CUS | Degree |
| CB | Cabinet Air Temperature | CUS | Degree |
| PLn* | Display Line Voltage | ENG | Volts |
| RCO* | Cycle Compressor Relay | ENG | On/Off |
| RdF* | Cycle Defrost Relay | ENG | On/Off |
| RFA* | Cycle Blower/Fan Relay | ENG | On/Off |
| RDH* | Cycle Door Heater Relay | ENG | On/Off |
| PRO* | Go To Bootloader For Programming | ENG | |
| CEP* | Clear EEPROM & Load Defaults | ENG | |
| REF* | Software Version/Revision/Step | n/a | |

*MIT II control version only.

VIII. CONTROL PARAMETERS

VIII. c - G-SERIES PARAMETER SETTINGS (MIT II Control Version):

| Control Parameter | Freezer Models | | | | Refrigerator Models | | |
|-------------------|---|---------|------|------|---------------------|------|------|
| | GF1 | GF2 | GF3 | GF4 | GR1 | GR2 | GR3 |
| ADR* | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| BAU* | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 |
| NAF* | ON | ON | ON | ON | ON | ON | ON |
| SPH | -5.2 | 0.1 | 0.1 | 32 | 38.1 | 39.2 | 39.2 |
| SPL | -10 | -4 | -4 | 26.1 | 34 | 37 | 37 |
| SHL | -8 | -3.1 | -3.1 | 30.2 | 36 | 39.2 | 39.2 |
| SHH | -5.2 | 0.1 | 0.1 | 34 | 40 | 40 | 40 |
| SLL | -13 | -6.2 | -6.2 | 26.1 | 32 | 34 | 34 |
| SLH | -10 | -4 | -4 | 28 | 34 | 37 | 37 |
| RO | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| HI | 0.1 | 5 | 5 | 35.2 | 41 | 41 | 41 |
| LO | -18.4 | -10 | -10 | 20 | 30.2 | 30.2 | 30.2 |
| SCL | F | F | F | F | F | F | F |
| HAD | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| LAD | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| AC | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| DEF | ELE | ELE | ELE | ELE | OFF | ELE | OFF |
| IBD | 4.0 | 4.0 | 4.0 | 4.0 | 1.0 | 2.0 | 1.0 |
| DDC | 20 | 20 | 20 | 20 | 10 | 20 | 10 |
| CDE | 75 | 75 | 75 | 75 | 45.1 | 70 | 45.1 |
| DDE | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| BDD | 1 | 1 | 1 | 1 | 0 | 0 | 0 |
| BSD | 32 | 32 | 32 | 32 | 32 | 32 | 32 |
| ODD | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| SD | Starts a new defrost cycle at any time or stops a current defrost cycle. | | | | | | |
| CFA | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| CCR | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| CDL | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| DOA | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| DAD | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| APD | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| ATD | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| AAS | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| CL | Set the hours and minutes in military time. | | | | | | |
| DAY | Set the year, month, day of the month and day of the week. | | | | | | |
| DS | ON | ON | ON | ON | ON | ON | ON |
| DL1 | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DL2 | OFF | 11:30am | OFF | OFF | OFF | OFF | OFF |
| DL3 | OFF | 5:30pm | OFF | OFF | OFF | OFF | OFF |
| DL4 | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DCF | n/a | n/a | n/a | n/a | n/a | n/a | n/a |
| CON | 19 | 19 | 19 | 19 | 11 | 11 | 11 |
| COF | 7 | 7 | 7 | 7 | 10 | 10 | 10 |
| EL | Will display evaporator coil temp in real time every time an arrow is pressed. | | | | | | |
| DL | Will display discharge line temp in real time every time an arrow is pressed. | | | | | | |
| CB | Will display cabinet air temp in real time every time an arrow is pressed. | | | | | | |
| PLn* | Will display power line voltage in real time every time an arrow is pressed. | | | | | | |
| RCO* | Turns ON/OFF the compressor relay for 10-seconds or until an arrow is pressed. | | | | | | |
| RdF* | Turns ON/OFF the defrost relay for 10-seconds or until an arrow is pressed. | | | | | | |
| RFA* | Turns ON/OFF the blower relay for 10-seconds or until an arrow is pressed. | | | | | | |
| RDH* | Turns ON/OFF the door heater triac for 10-seconds or until an arrow is pressed. | | | | | | |
| PRO* | Set the controller in receiving mode for programming. | | | | | | |
| CEP* | Clear all controller memories and reloads the factory default parameters. | | | | | | |
| REF* | Firmware revision in the format X9.9 (X=version, 9=major revision, 9=minor revision). | | | | | | |

*MIT II control version only.

VIII. CONTROL PARAMETERS

VIII. d - R-SERIES PARAMETER SETTINGS (MIT II Control Version):

| Control Parameter | Refrigerator Models | | | | | | | |
|-------------------|---|-------|-------|-------|-------|-------|-------|-------|
| | RA1 | RA2 | RA3 | RA4 | RA5 | RA6 | RA7 | RA8 |
| ADR | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| BAU | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 |
| NAF | ON | ON | ON | ON | ON | ON | ON | ON |
| SPH | 39.2 | 39.2 | 39.2 | 39.2 | 38.1 | 38.1 | 39.2 | 39.2 |
| SPL | 37 | 37 | 37 | 37 | 34 | 34 | 37 | 37 |
| SHL | 39.2 | 39.2 | 39.2 | 39.2 | 36 | 36 | 39.2 | 39.2 |
| SHH | 40 | 40 | 40 | 40 | 40 | 40 | 40 | 40 |
| SLL | 34 | 34 | 34 | 34 | 32 | 32 | 34 | 34 |
| SLH | 37 | 37 | 37 | 37 | 34 | 34 | 37 | 37 |
| RO | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| HI | 41 | 41 | 41 | 41 | 41 | 41 | 41 | 41 |
| LO | 30.2 | 30.2 | 30.2 | 30.2 | 30.2 | 30.2 | 30.2 | 30.2 |
| SCL | F | F | F | F | F | F | F | F |
| HAD | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 |
| LAD | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| AC | 3 | 3 | 3 | 3 | 3 | 3 | 3 | 3 |
| DEF | OFF | OFF | OFF | OFF | OFF | OFF | ELE | ELE |
| IBD | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 | 1.0 | 2.0 | 2.0 |
| DDC | 10 | 10 | 10 | 10 | 10 | 10 | 20 | 20 |
| CDE | 45.1 | 45.1 | 45.1 | 45.1 | 45.1 | 45.1 | 70 | 70 |
| DDE | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| BDD | 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| BSD | 32 | 32 | 32 | 32 | 32 | 32 | 32 | 32 |
| ODD | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| SD | Starts a new defrost cycle at any time or stops a current defrost cycle. | | | | | | | |
| CFA | OFF | ON | OFF | ON | ON | ON | OFF | ON |
| CCR | 20 | 20 | 20 | 20 | 20 | 20 | 20 | 20 |
| CDL | 220.1 | 220.1 | 220.1 | 220.1 | 220.1 | 220.1 | 220.1 | 220.1 |
| DOA | ON | ON | ON | ON | ON | ON | ON | ON |
| DAD | 15 | 15 | 15 | 15 | 15 | 15 | 15 | 15 |
| APD | 2 | 2 | 2 | 2 | 2 | 2 | 2 | 2 |
| ATD | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| AAS | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| CL | Set the hours and minutes in military time. | | | | | | | |
| DAY | Set the year, month, day of the month and day of the week. | | | | | | | |
| DS | ON | ON | ON | ON | ON | ON | ON | ON |
| DL1 | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DL2 | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DL3 | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DL4 | OFF | OFF | OFF | OFF | OFF | OFF | OFF | OFF |
| DCF | 100 | 100 | 100 | 100 | 100 | 100 | 100 | 100 |
| CON | 11 | 11 | 11 | 11 | 11 | 11 | 11 | 11 |
| COF | 10 | 10 | 10 | 10 | 10 | 10 | 10 | 10 |
| EL | Will display evaporator coil temp in real time every time an arrow is pressed. | | | | | | | |
| DL | Will display discharge line temp in real time every time an arrow is pressed. | | | | | | | |
| CB | Will display cabinet air temp in real time every time an arrow is pressed. | | | | | | | |
| PLN* | Will display power line voltage in real time every time an arrow is pressed. | | | | | | | |
| RCO* | Turns ON/OFF the compressor relay for 10-seconds or until an arrow is pressed. | | | | | | | |
| RdF* | Turns ON/OFF the defrost relay for 10-seconds or until an arrow is pressed. | | | | | | | |
| RFA* | Turns ON/OFF the blower relay for 10-seconds or until an arrow is pressed. | | | | | | | |
| RDH* | Turns ON/OFF the door heater triac for 10-seconds or until an arrow is pressed. | | | | | | | |
| PRO* | Set the controller in receiving mode for programming. | | | | | | | |
| CEP* | Clear all controller memories and reloads the factory default parameters. | | | | | | | |
| REF* | Firmware revision in the format X9.9 (X=version, 9=major revision, 9=minor revision). | | | | | | | |

*MIT II control version only.

VIII. CONTROL PARAMETERS

VIII. e - R-SERIES PARAMETER SETTINGS (MIT II Control Version):

| Control Parameter | Freezer Models | | | | |
|----------------------|---|-------|-------|-------|-------|
| | RF1 | RF2 | RF3 | RF4 | RF5 |
| ADR | 2 | 2 | 2 | 2 | 2 |
| BAU | 9.6 | 9.6 | 9.6 | 9.6 | 9.6 |
| NAF | ON | ON | ON | ON | ON |
| SPH | -15.4 | -10 | 0.1 | 0.1 | -5.2 |
| SPL | -20.2 | -15.4 | -4 | -4 | -10 |
| SHL | -15.4 | -13.6 | -2.2 | -2.2 | -8 |
| SHH | -10 | -10 | 0.1 | 0.1 | -5.2 |
| SLL | -20.2 | -20.2 | -6.2 | -6.2 | -13 |
| SLH | -17 | -15.4 | -4 | -4 | -10 |
| RO | 0 | 0 | 0 | 0 | 0 |
| HI | 5.2 | 5.2 | 5 | 5 | 0.1 |
| LO | -25.6 | -25.6 | -10 | -10 | -17.8 |
| SCL | F | F | F | F | F |
| HAD | 15 | 15 | 15 | 15 | 15 |
| LAD | 2 | 2 | 2 | 2 | 2 |
| AC | 3 | 3 | 3 | 3 | 3 |
| DEF | ELE | ELE | ELE | ELE | ELE |
| IBD | 4.0 | 4.0 | 4.0 | 4.0 | 4.0 |
| DDC | 30 | 20 | 20 | 20 | 20 |
| CDE | 55 | 75 | 75 | 70 | 70 |
| DDE | 5 | 2 | 2 | 2 | 2 |
| BDD | 1 | 1 | 1 | 1 | 1 |
| BSD | -10 | 32 | 32 | 32 | 32 |
| ODD | 10 | 10 | 10 | 10 | 10 |
| SD | Starts a new defrost cycle at any time or stops a current defrost cycle. | | | | |
| CFA | ON | OFF | OFF | ON | ON |
| CCR | 20 | 20 | 20 | 20 | 20 |
| CDL | 220.1 | 220.1 | 220.1 | 220.1 | 220.1 |
| DOA | ON | ON | ON | ON | ON |
| DAD | 15 | 15 | 15 | 15 | 15 |
| APD | 2 | 2 | 2 | 2 | 2 |
| ATD | 10 | 10 | 10 | 10 | 10 |
| AAS | OFF | OFF | OFF | OFF | OFF |
| CL | Set the hours and minutes in military time. | | | | |
| DAY | Set the year, month, day of the month and day of the week. | | | | |
| DS | ON | ON | ON | ON | ON |
| DL1 | OFF | OFF | OFF | OFF | OFF |
| DL2 | OFF | OFF | OFF | OFF | OFF |
| DL3 | OFF | OFF | OFF | OFF | OFF |
| DL4 | OFF | OFF | OFF | OFF | OFF |
| DCF | 100 | 100 | 100 | 100 | 100 |
| CON | 19 | 19 | 19 | 19 | 19 |
| COF | 7 | 7 | 7 | 7 | 7 |
| EL | Will display evaporator coil temp in real time every time an arrow is pressed. | | | | |
| DL | Will display discharge line temp in real time every time an arrow is pressed. | | | | |
| CB | Will display cabinet air temp in real time every time an arrow is pressed. | | | | |
| PLn | Will display power line voltage in real time every time an arrow is pressed. | | | | |
| RCO | Turns ON/OFF the compressor relay for 10-seconds or until an arrow is pressed. | | | | |
| RdF | Turns ON/OFF the defrost relay for 10-seconds or until an arrow is pressed. | | | | |
| RFA | Turns ON/OFF the blower relay for 10-seconds or until an arrow is pressed. | | | | |
| RDH | Turns ON/OFF the door heater triac for 10-seconds or until an arrow is pressed. | | | | |
| PRO | Set the controller in receiving mode for programming. | | | | |
| CEP | Clear all controller memories and reloads the factory default parameters. | | | | |
| REF | Firmware revision in the format X9.9 (X=version, 9=major revision, 9=minor revision). | | | | |

VIII. CONTROL PARAMETERS

VIII. f - UNDERCOUNTER PARAMETER SETTINGS (MIT II Control Version):

| Control Parameter | UF1 | UF2 | UP1 | UP2 |
|-------------------|---|-------|------|-------|
| ADR | 2 | 2 | 2 | 2 |
| BAU | 9.6 | 9.6 | 9.6 | 9.6 |
| NAF | ON | ON | ON | ON |
| SPH | 0.1 | 38.1 | 38.1 | 38.1 |
| SPL | -4 | 33.8 | 33.8 | 33.8 |
| SHL | -0.31 | 36 | 36 | 36 |
| SHH | 0.1 | 40 | 40 | 40 |
| SLL | -6.2 | 32 | 32 | 32 |
| SLH | -4 | 34 | 34 | 34 |
| RO | 0 | 0 | 0 | 0 |
| HI | 5 | 41 | 41 | 41 |
| LO | -10 | 30.2 | 30.2 | 30.2 |
| SCL | F | F | F | F |
| HAD | 15 | 15 | 15 | 15 |
| LAD | 2 | 2 | 2 | 2 |
| AC | 3 | 3 | 3 | 3 |
| DEF | GAS | GAS | OFF | OFF |
| IBD | 4.0 | 4.0 | 1.0 | 1.0 |
| DDC | 20 | 20 | 10 | 10 |
| CDE | 75 | 75 | 45.1 | 45.1 |
| DDE | 5 | 2 | 2 | 2 |
| BDD | 1 | 1 | 0 | 0 |
| BSD | -10 | 32 | 32 | 32 |
| ODD | 10 | 10 | 10 | 10 |
| SD | Starts a new defrost cycle at any time or stops a current defrost cycle. | | | |
| CFA | OFF | OFF | N/A | OFF |
| CCR | 20 | 20 | N/A | 20 |
| CDL | 220.1 | 220.1 | N/A | 220.1 |
| DOA | OFF | OFF | N/A | OFF |
| DAD | 15 | 15 | N/A | 15 |
| APD | 2 | 2 | 2 | 2 |
| ATD | 10 | 10 | N/A | 10 |
| AAS | OFF | OFF | N/A | OFF |
| CL | Set the hours and minutes in military time. | | | |
| DAY | Set the year, month, day of the month and day of the week. | | | |
| DS | ON | ON | ON | ON |
| DL1 | OFF | OFF | OFF | OFF |
| DL2 | OFF | OFF | OFF | OFF |
| DL3 | OFF | OFF | OFF | OFF |
| DL4 | OFF | OFF | OFF | OFF |
| DCF | 100 | 100 | 100 | 100 |
| CON | 19 | 19 | 11 | 11 |
| COF | 7 | 7 | 10 | 10 |
| EL | Will display evaporator coil temp in real time every time an arrow is pressed. | | | |
| DL | Will display discharge line temp in real time every time an arrow is pressed. | | | |
| CB | Will display cabinet air temp in real time every time an arrow is pressed. | | | |
| PLn | Will display power line voltage in real time every time an arrow is pressed. | | | |
| RCO | Turns ON/OFF the compressor relay for 10-seconds or until an arrow is pressed. | | | |
| RdF | Turns ON/OFF the defrost relay for 10-seconds or until an arrow is pressed. | | | |
| RFA | Turns ON/OFF the blower relay for 10-seconds or until an arrow is pressed. | | | |
| RDH | Turns ON/OFF the door heater triac for 10-seconds or until an arrow is pressed. | | | |
| PRO | Set the controller in receiving mode for programming. | | | |
| CEP | Clear all controller memories and reloads the factory default parameters. | | | |
| REF | Firmware revision in the format X9.9 (X=version, 9=major revision, 9=minor revision). | | | |

HOURS OF OPERATION:

Monday thru Friday 7:30 am - 4:30 pm CST



Quality Refrigeration

Traulsen

4401 Blue Mound Road Fort Worth, TX 76106
Phone: (800) 825-8220 Fax-Svce: (817) 740-6757
Website: www.traulsen.com