## TROUBLESHOOTING YOUR MILK COOLER

## 

## **CHALLENGES**

- Condensing Unit Has No Power or Fails to Start
- 2. Condensing Unit Operates Continuously
- 3. Food Compartment Too Warm/Cold
- 4. Condensation on Exterior Surface

## **SOLUTIONS**

- 1. Check if cord & plug has been disconnected. Check control temperature setting and power breaker.
- 2. Check doors for proper sealing. Clean dirty condenser or filter if needed.
- 3. If a large quantity of food has been added or the door was left open for a long period of time, allow adequate time for the cabinet to recover to normal operating temperature. Check that condensing coil is clean.
- 4. Check door alignment and gaskets for proper seal.

  Condensation on exterior surface is normal during periods of high humidity.







