centerline
by HOBART

PROGRAM SETTINGS – Access Changing Parameters

1. Press Menu Button   **2. EXIT MENU** – OPEN door and close

00 = Extended Wash – 3-6 minute limit

°F 00 / 4 °C → **Change Setpoint by** — **Increase** / **Decrease** → **EXIT MENU OPEN DOOR**

01 = Cycle Count – Counter reading has 6 digits (012345 cycle)

°F 01 °C → 01 / 012 °C → 01 / 345 °C → **EXIT MENU OPEN DOOR**

02 = Detergent Dispensing – 0.0-9.5g/l

°F 02 / 2.0 °C → **Change Setpoint by** — **Increase** / **Decrease** → **EXIT MENU OPEN DOOR**

03 = Prime Detergent Pump – Repeat as needed to prime the line

°F 03 / 0 °C → 03 / 1 °C → 03 / .1 °C Flashing (Dot) Pump On → **EXIT MENU OPEN DOOR**

04 = Rinse Aid Dispensing – 0.0-2.0g/l

°F 04 / 0.3 °C → **Change Setpoint by** — **Increase** / **Decrease** → **EXIT MENU OPEN DOOR**

05 = Prime Rinse Aid Pump – Repeat as needed to prime the line

°F 05 / 0 °C → 05 / 1 °C → 05 / .1 °C Flashing (Dot) Pump On → **EXIT MENU OPEN DOOR**

06 = Sanitizer Dispensing – Range can be 0-100%   For CUL Model Only

°F 06 / 50 °C → **Change Setpoint by** — **Increase** / **Decrease** → **EXIT MENU OPEN DOOR**

07 = Prime Sanitizer Pump – Repeat as needed to prime the line

°F 07 / 0 °C → 07 / 1 °C → 07 / .1 °C Flashing (Dot) Pump On → **EXIT MENU OPEN DOOR**

08 = Temperature Label (°F/°C)

°F 08 / F °C → **Change Setpoint by** — **Increase** / **Decrease** → **EXIT MENU OPEN DOOR**